

## Decal Application Instructions

Thank you for your decal purchase. Your decal should be applied as soon as possible to prevent application issues. Decals should be applied only to surfaces with temperatures between 50 to 90 degrees Fahrenheit and should be allowed to cure for 24 hours before getting wet. Your decal comes with transfer tape applied to help you easily install it.

### Supplies: Decal and a vinyl applicator or old credit card

**Step 1)** Clean the surface where you will apply the decal. Windex usually does the trick, but make sure you let it dry.

**Step 2)** Lining up the decal: With the backing paper still attached, hold the decal up against the trunk to get a sense of how it will look and if it will fit in the area you've chosen. This will give you a sense of the best placement for it.

**Step 3)** Decal Prep: Firmly press the clear transfer tape to the decal. Beginning in a corner, slowly peel the backing paper off, leaving the decal on the transfer tape.



**Step 4)** Apply: Once the decal is lined up, use the vinyl applicator or an old credit card to rub it firmly from the center point to the edges in all directions to remove air bubbles.



**Step 5)** Beginning in a corner, slowly peel away the transfer tape at a 45 degree angle. Enjoy your decal!

